

# PLEASE READ THE FOLLOWING PRIOR TO OPERATION OF THIS EQUIPMENT!

The following are basic safety precautions to understand when operating this Boom Lift or Scissor Lift; also known as a Mobile Elevated Work Platform (MEWP). It is NOT intended to be a complete list of safety precautions. Please review the Operator Manual prior to operation. If one is not on the machine, contact All Star Rents and we will supply one to you prior to operating lift.

## Basic Operation & Safety Requirements



This symbol means: **Attention! Be Alert! Your safety is involved!** The safety alert symbols found on decals and in the Operator Manual alert you to potential safety hazards. Obey all safety messages with this symbol to avoid possible injury or death.

Other similar symbols: **⚠ WARNING** **⚠ DANGER** **⚠ CAUTION**



Refer to the Operator Manual for any operational or safety questions you may have. Contact All Star Rents prior to operation if one is not located on the machine. If you are new to operating this machine you should practice in a safe area and refer to Operator Manual for instructions

An ANSI Manual of Responsibilities is in the manual box. This manual details your responsibilities as a User and/or Operator of this MEWP. It is critical to your safety to abide by the information contained in this manual.

Per ANSI regulations any User of this MEWP must have received, or ensure the Operator has received, a prescribed level of training as detailed in the Manual of Responsibilities. Training is available through All Star Rents. The Familiarization we provide at the time of rental is not to be considered a substitute for this training.

A harness and lanyard are required to be worn while operating any “boom” type lift. A new harness and lanyard will be offered to you to purchase at the time of rental. This type of fall protection is typically not required while operating a scissor lift. However, local rules or specific machines may require it. Refer to the Operator Manual.

**ALWAYS** position the MEWP away from power lines. Refer to the Owner’s Manual for safe operating distances from power lines.

**NEVER** exceed the capacity of the MEWP. **NEVER** use it as a crane or lifting device for materials. **NEVER** use a MEWP to support a banner or flags. Refer to manual for use in windy conditions.

We advise you to keep a cellular phone on you in the event you need to call for assistance while elevated in the MEWP.



Contact All Star Rents immediately if you have any problems with the machine. DO NOT attempt to repair, upright or start the machine if it has tipped over. Doing so could result in further injury or damage to the equipment. Call 911 first if serious injury as occurred while operating the MEWP.

## All Star Rents Toll Free: 866-ALL STAR